



SUBARU

Fahrgestellnummer - Aufschlüsselung

SUBARU LEGACY + OUTBACK - ab MJ 04

J	F	1	B	L	5	L	J	3	4	G	0	0	0	0	0	0	1	
																	Fortlaufende Nummer	
																	Herstellerwerk G = GUNMA-Werk	
																	Modelljahr: 4 = 2004 7 = 2007 5 = 2005 8 = 2008 6 = 2006 9 = 2009	
																	Getriebe: 3 = MT, Single Range 4 = MT, Dual Range 5 = Automatik A = Automatik, Outback B = MT, Dual Range, Outback E = MT, Single Range, Outback F = MT, Single Range, Outback, Sunroof G = MT, Single Range, Sunroof	
																	Motor / Getriebe: J = SOHC 5MT Single-range K = SOHC 5MT Dual-range L = SOHC 4AT Sports-shift M = DOHC 5MT Dual-range F = DOHC 5MT Single-range U = DOHC 5AT Sports-shift N = DOHC 5MT Single-range S = DOHC 4AT Sports-shift W = DOHC 5MT Dual-range Y = DOHC 5MT Single Range Diesel	
																	L = Linkslenker K = Rechtslenker	
																	Motor: 5 = 2000 cm ³ 4WD 9 = 2500 cm ³ 4WD E = 3000 cm ³ 4WD D = 2000 cm ³ 4WD Diesel	
																	Karosserie: L = 4-türig, Limousine P = 5-türig, Kombi	
																	Fahrzeuglinie	
																	Fahrzeugart: 1 = Pkw	
																	Hersteller: Fuji Heavy Industries Ltd.	
																	Japan	

Typ/Zeichn.Nr.: BL/BP	Technische Information	Datum: 12.2008
---------------------------------	-------------------------------	--------------------------